



Distributed By
Freeman Manufacturing & Supply Co.
www.freemansupply.com 800-321-8511

Sustainable Performance™

P.O. Box 1825 Ellijay, GA 30540 • (706) 698-4405 • (800) 858-4111 • Fax: (706) 635-8103 • www.zyvax.com

SURFACE CLEANER

DESCRIPTION

SURFACE CLEANER is a combination of solvents specially blended to aid in the preparation of new and used molds and plugs prior to treatment with ZYVAX MOLD CONDITIONERS AND RELEASE AGENTS. It readily removes waxes and other surface contaminants without harming or dulling the working surfaces of the mold. For the 100% SOLVENT-FREE mold release system best suited to your needs, see our website: www.zyvax.com.

SURFACE CLEANER BENEFITS

- * Can be used to remove all release agents
- * Ease of application and use
- * No residue
- * Fast drying

USES

SURFACE CLEANER is safe and effective cleaning for molds, molds, equipment and finished parts and will remove uncured resin or gelcoat. **SURFACE CLEANER** will also clean brushes and spray equipment used to apply various release products and elastomeric materials.

HOW TO USE

1. Apply **SURFACE CLEANER** liberally to the surface of the mold with a clean cloth.
2. As the waxes and other contaminants begin to dissolve and loosen, remove them from the surface while still wet using a separate clean cloth or abrasive pad.
Make sure entire mold surface is cleaned in this manner, slightly over-lapping the last area if you are working in sections. Be certain that all contours are adequately cleaned.
3. Repeat this process until the entire mold is clean.
The cleaning cloths should be regularly replaced as they become saturated with wax, etc.
4. When all the contaminants have been removed, wipe the entire surface with a clean cloth soaked with **SURFACE CLEANER**, and buff until dry.

SAFETY DATA

Material safety data sheets for all ZYVAX products are available at www.zyvax.com and should be consulted prior to use of product.

STORAGE & SHELF LIFE

Store product between 5 °C and 30 °C (41 °F and 86 °F). Shelf life is 18 months from the date of manufacture, in the original unopened container.

USE LIFE

Use life of product is 60 days from opening of container. Product must be kept in the original container and the lid replaced immediately after dispensing. After opening, product should continue to be stored properly. **WARNING** *Never puncture any ZYVAX product container.*

LIMITATIONS OF LIABILITY

To the best of our knowledge, the technical data contained herein are true and accurate at the date of issuance, and are subject to change without prior notice. User must contact **ZYVAX** to verify correctness before specifying or ordering. No guarantee of accuracy is given or implied. We guarantee our products to conform to **ZYVAX** quality control. We assume no responsibility for coverage, performance, or injuries resulting from its use. Liability, if any, is limited to replacement of products. NO OTHER WARRANTY OR GUARANTEE OF ANY KIND IS MADE BY **ZYVAX**, EXPRESSED OR IMPLIED, STATUTORY, BY OPERATION OF LAW OR OTHERWISE, INCLUDING FITNESS FOR A PARTICULAR PURPOSE.