



A Chem-Trend Brand

P.O. Box 860 • Howell, MI 48844-0860

517.546.4520 • 800.746.4773

Fax: 517.546.8910

Zyvax.com

Waterclean – Solvent-Free Mold and Finished Parts Cleaner

Description

Waterclean has been developed to provide an effective solvent-free alternative to solvent washing for the removal of surface contaminants from molds and molded parts. Waterclean is non-flammable and will not harm the surface. Waterclean eliminates solvent washing when preparing parts for painting, bonding or other processes that require a completely clean surface. For the mold release system best suited to your needs, see our website: www.zyvax.com.

Waterclean Benefits

- Easy to apply
- Low odor
- Cost effective
- Non-flammable
- Solvent-free

Uses

Waterclean is suitable for all surfaces including gelcoat. Waterclean is recommended for effective cleaning of molds, molds, equipment and finished parts.

How To Use

Waterclean should appear uniform in container. If not, then shake or stir.

1. Apply a SMALL amount directly to the dry mold surface.
2. Using a damp paper towel, scrub the surface. Work with small sections until the entire surface is scrubbed. DO NOT allow Waterclean to dry on the surface.
3. Remove using only clean WATER. This can be done by rinsing with a wet cloth or water sprayer. Rinse until no residue remains; the surface should feel clean. Rinsing will highlight areas that require more cleaning.
4. Repeat until a waterbreak-free surface is achieved.
5. You are now ready to apply a sealer and release agent.

Safety Data

Material safety data sheets for all Zyvox® products are available at www.zyvax.com and should be consulted prior to use of product.

Storage & Shelf Life

Store product between 5°C and 30°C (41°F and 86°F). Shelf life is 18 months from the date of manufacture, in the original unopened container. NOTE: Waterclean *needs to be carefully sealed when not in use in order to avoid water evaporation.*

Use Life

Use life of product is 60 days from opening the container. Product must be kept in the original container and the lid replaced immediately after dispensing. After opening, the product should be stored properly.

WARNING: *Never puncture any Zyvox® product container.*

While the technical information and suggestions for use contained herein are believed to be accurate and reliable, nothing stated in this bulletin is to be taken as a warranty either expressed or implied



Become a member!

Distributed By
Freeman Manufacturing & Supply Co.
www.freemansupply.com 800-321-8511

