February 2012 Moldmaking 360 member **BLUESIL[™] V 1082 Distributed By** Freeman Manufacturing & Supply Co. www.freemansupply.com 800-321-8511 FREEMAN Condensation Cure Silicone Elastomer BLUESIL[™] V 1082 is a translucent, high strength, two component, tin catalyzed, room Description temperature cure silicone rubber. It is a medium viscosity material providing excellent cured rubber properties, long library life and life-like texture. BLUESIL[™] V 1082 is the most flexible and softest rubber in the Bluestar Silicones moldmaking product line - two clear catalysts are available, HiProClear and HiPro ST ~ PEX, depending on the desired hardness. BLUESIL W V **1082** can be easily pigmented, which makes it ideal for robotic or animatronic skins, prosthetics, and props for theme parks and the film industry. Applications Skins for robotic and animatronic figures for both indoor and outdoor applications · Special effect skins and props for the film industry • Theme park props and reproduction molds Typical As Supplied: **Properties** Part A Base Component Color Translucent Consistency Viscous Liquid Viscosity, cps 40 000 Part B Catalyst Component Color Translucent · Viscosity, cps 100 **Catalyzed Properties** Mixed at ~ 24°C (75°F) and 50% RH Mix Ratio (by Weight) 10:1 Viscosity, cps
Work Life⁽¹⁾, minutes 30 000 120 • Pot Life⁽²⁾, minutes 300 Typical Cure Rubber Properties ~ 7 days at ~ 24°C (75°F) and 50% RH) Property Method Value **HiPro Clear** HiPro ST ~ PEX Color Translucent Translucent Specific Gravity 1.10 1.10 · Hardness, **ASTM 2240** 9 Shore A 40 Shore 00 • Tensile, psi ASTM 412 480 550 • Elongation, % **ASTM 412** 570 550 Tear, ppi ASTM D624 100 110 • Linear Shrinkage⁽³⁾, % 0.2 0.2 ~ room temperature 24 hrs 7 davs 0.4 0.4 • Temperature Range, C° (F°) -50 to 150 (-58 to 302)

(1) Time to double in viscosity (2) Snapback Time (3) 8 x 8 x 0.25 inch molded sheet ,cured at room temperature <u>Please note</u>: The typical properties listed in this bulletin are not intended for use in preparing specifications for any particular application

of Bluesil[®] silicone materials. Please contact our Technical Service Department for assistance in writing specifications.





February 2012

 BLUESLL[™] V 1082 Instructions for use Stir the base (Part A) well before use (except when machine dispensing). Shake the catalyst container (Part B) well before use. Weigh the desired amount of base into a clean mixing container. Tip the container and roll the base all the way around the side wall up to two inches from the top. This will prevent the catalyst from becoming absorbed into the container. It is recommended that the container be filled to not more than 1/3 the container depth to allow sufficient room for expansion during the deaeration procedure. Weigh the proper amount of catalyst into the container. Mix the base and catalyst together by stirring with a stiff, flat ended metal spatula until a uniform color is obtained. Scrape the container walls and bottom well to insure a thorough mix Place the container into a vacuum chamber and evacuate the entrapped air from the mixture using a vacuum pump capable of achieving 29 inches of mercury vacuum. The mixture will rise, crest and then collapse in the container. Interruption (bumping) of the vacuum chamber. When the chamber is at atmospheric equilibrium, remove the cover plate and take out the container. Pour the deaired material <u>slowly</u> in a steady stream from one end of the mold box so that the material flows evenly over the pattern. This should minimize entrappend of air bubbles under the flowing material. A "print" coat may be poured firs over the pattern which will also help reduce the possibility of entrapping air on the pattern and in the cured rubber. A mole release (petroleum jelly) may be applied on the pattern first to improve release. Allow the rubber to cure for 16-24 hours at 75±5°F (24°C) before removing the cured rubber mold from the pattern. Heat acceleration is not recommended with this product. For bost results, allow the mold to air cure an additional 24 hours before using it in production. Full cure is a
 Instructions for use Shake the catalyst container (Part B) well before use. Weigh the desired amount of base into a clean mixing container. Tip the container and roll the base all the way around the side wall up to two inches from the top. This will prevent the catalyst from becoming absorbed into the container. It is recommended that the container be filled to not more than 1/3 the container depth to allow sufficient room for expansion during the deaeration procedure. Weigh the proper amount of catalyst into the container. Mix the base and catalyst together by stirring with a stiff, flat ended metal spatula until a uniform color is obtained. Scrape the container walls and bottom well to insure a thorough mix Place the container into a vacuum chamber and evacuate the entrapped air from the mixture using a vacuum pump capable of achieving 29 inches of mercury vacuum. The mixture will rise, crest and then collapse in the container. Interruption (bumping) of the vacuum may be necessary to prevent overflowing the container. Keep the mixture under ful vacuum for 2-3 minutes after the material has receded in the container. Bleed air slowly into the vacuum chamber. When the chamber is at atmospheric equilibrium, remove the cover plate and take out the container. Pour the deaired material <u>slowly</u> in a steady stream from one end of the mold box so that the material flows evenly over the pattern. This should minimize entrapment of air bubbles under the flowing material. A "print" coat may be poured firs over the pattern which will also help reduce the possibility of entrapping air on the pattern and in the cured rubber. A mole release (petroleum jelly) may be applied on the pattern first to improve release. Allow the rubber to cure for 16-24 hours at 75±6°F (24°C) before removing the cured rubber mold from the pattern. Heat acceleration is not recommended with this product. For best results, allow the mol
PROCESSING INFORMATION CATALYZED PROCESSING PROPERTIES ARE AFFECTED BY TEMPERATURE AND HUMIDITY VARIATION For best results, mix and cure the material at 75°F (24°C) and 50% relative humidity. Higher temperature and humidity will <u>decrease</u> the work life and pot life of the material. The faster cure will also affect the flow properties. Refrigeration of the base prior to use in hot environments has shown to improve the handling properties or this material. Lower temperatures and humidity will <u>increase</u> the work life and pot life of the material. The slower cure will increase the flow time. Cure temperatures below 68°F (20°C) are not recommended and have been found to cause a reduction in fina cure hardness and properties. It is important that the catalyst containers are <u>tightly closed after use</u> . Catalyst exposed to air for extended periods of time will hydrolyze (cure). An indication of hydrolysis is a film or crust formation on the surface of the catalyst. The use of hydrolyzed catalyst is not recommended and may cause incomplete cure.
Storage and Shelf LifeBLUESIL [™] V 1082 when stored in its original unopened packaging, at 24°C (77°F), may be store for 36 months from the date of manufacture. Beyond this date, Bluestar Silicones no longer guarantees that the product meets the sales specifications
Safety Please read the container labels for BLUESIL [™] V 1082 or consult the Material Safety Data Shee (MSDS) before handling for safe use, physical and health hazard information. The MSDS is not included with the product packaging, but can be obtained by contacting Bluestar Silicones at 866 474-6342 or consult your Bluestar Silicones representative.
Packaging BLUESIL [™] V 1082 is available in 20 kg and 200 kg containers.

EUROPE	NORTH AMERICA	C LATIN AMERICA	ASIA PACIFIC
Bluestar Silicones France	Bluestar Silicones USA	Bluestar Silicones Brazil Ltda.	Bluestar Silicones Hong Kong
21 Avenue Georges Pompidou	Two Tower Center Boulevard Suite	Av. Maria Coelho Aguiar, 215	Trading Co. Ltd.
F69486 Lyon Cedex 03	1601	Bloco G - 1º Andar	29 th Floor, 88 Hing Fat Street
FRANCE	East Brunswick, NJ 08816-1100	05804-902 - São Paulo - SP - Brazil	Causeway Bay
Tel. (33) 4 72 13 19 00 Fax (33) 4 72 13 19 88	United States Tel. (1) 732 227 2060 Fax (1) 732 249 7000	Tel. (55) 11 3747 7887 Fax (55) 11 3741 7718	Hong Kong Tel. (852) 3106 8200 Fax (852) 2979 0241

Warning to the users

The information contained in this document is given in good faith based on our current knowledge. It is only an indication and is in no way binding, particularly as regards infringement of or prejudice to third party rights through the use of our products. BLUESTAR SILICONES guarantees that its products comply with its sales specifications. This information must on no account be used as a substitute for necessary prior tests which alone can ensure that a product is suitable for given use. Determination of the suitability of Product for the uses and applications contemplated by Buyer and others shall be the sole responsibility of Buyer. Users are responsible for ensuring compliance with local legislation and for obtaining the necessary certifications and authorizations. Users are requested to check that they are in possession of the latest version of this document and **BLUESTAR SILICONES** is at their disposal to supply any additional information.



Bluestar Silicones. Delivering Your Potential. www.bluestarsilicones.com



BLUESIL[™] is a Trademark of Bluestar Silicones