

BLUESIL™ RTV 3044 A&B

Distributed by
Freeman Manufacturing & Supply Co.
www.freemansupply.com (800) 321-8511

**Prototyping****Description**

BLUESIL™ RTV 3044 is a 1:1 mix ratio, two-component clear, high strength, addition cure silicone rubber compound. It is formulated to cure overnight at room temperature or within hours at elevated temperature to give a hardness of approximately 38 ShA. Its low viscosity makes the product easy to pour and quick to degas.

BLUESIL™ RTV 3044 is designed to serve the needs of the prototyper by reproducing intricate details and maintaining tight tolerances. In addition, **BLUESIL™ RTV 3044** has been formulated to provide improved urethane resin resistance.

Applications

- Conventional production and prototype molds
- Finished rubber parts
- Stereolithography (SLA) molds

Typical Properties

TYPICAL PROPERTIES - AS SUPPLIED		TYPICAL CATALYZED PROPERTIES	
<u>Part A - Base Component</u>		Mixed at 24°C (75°F) and 50% R.H.	
• Color	Translucent	• Mix Ratio , A:B(Parts by weight)	1:1
• Consistency	Pourable	• Viscosity , cP. (mPa.s)	40,000
• Viscosity , cP. (mPa.s)	58,000		
<u>Part B – Component</u>			
• Color	Translucent		
• Viscosity , cP. (mPa.s)	29,000		
TYPICAL PROPERTIES OF CURED RUBBER, Cured 24 hours at 24°C (75°F) and 50% RH			
<u>Property</u>	<u>Test Method</u>	<u>RTV 3044 A/B</u>	
• Color		Translucent	
• Specific Gravity		1.09	
• Work Life , hours ⁽¹⁾		2.00	
• Pot Life , hours ⁽²⁾		2.00	
• Hardness (Shore A)	ASTM D2240	38	
• Tensile Strength , psi (N/mm ²)	ASTM D412	809	
• Elongation (%)	ASTM D412	372	
• Tear Resistance , ppi (N/mm)	ASTM D624, Die B	114	
• Linear Shrinkage ⁽³⁾ (%) 24 Hours		< 0.1	
7 Days		< 0.1	
• Temperature Range °C (°F)		-54 to 204 (-65 to 400)	
NOTE: Cure may be accelerated by curing at 40-65°C (120-150°F) for 3-4 hours. HEAT CURING MAY INCREASE SHRINKAGE.			

(1) Time required to double initial catalyzed viscosity.

(3) 8x8x0.25 in (20.3x20.3x0.64 cm) molded sheet, cured at room temperature

(2) Time at which material gels.

NOTE: Cure at elevated temperatures may cause modification of rubber properties and increase shrinkage.

Please note: The typical properties listed in this bulletin are not intended for use in preparing specifications for any particular application of BLUESIL™ silicone materials. Please contact our Technical Service Department for assistance in writing specifications.

BLUESIL™ RTV 3044 A&B

Distributed by
 Freeman Manufacturing & Supply Co.
 www.freemansupply.com (800) 321 8511 **FREEMAN**

Instructions for use

1. Stir the base (Part A) well before use (except when machine dispensing).
2. Weigh the desired amount of base into a clean mixing container. Tip the container and roll the base all the way around the side-wall up to two inches from the top. This will prevent the catalyst from becoming absorbed into the container. It is recommended that the container be filled to not more than 1/3 the container depth to allow sufficient room for expansion during the de-aeration procedure.
3. Weigh the proper amount of catalyst into the container. Mix the base and catalyst together by stirring with a stiff, flat ended metal spatula until a uniform color is obtained. Scrape the container walls and bottom well to insure a thorough mix.
4. Place the container into a vacuum chamber and evacuate the entrapped air from the mixture using a vacuum pump capable of achieving 29 inches of mercury vacuum. The mixture will rise, crest and then collapse in the container. Interruption (bumping) of the vacuum may be necessary to prevent overflowing the container. Keep the mixture under full vacuum for 2-3 minutes after the material has receded in the container.
5. Bleed air slowly into the vacuum chamber. When the chamber is at atmospheric equilibrium, remove the cover plate and take out the container.
6. Pour the deaired material slowly in a steady stream from one end of the mold box so that the material flows evenly over the pattern. This should minimize entrapment of air bubbles under the flowing material. A "print" coat may be poured first over the pattern which will also help reduce the possibility of entrapping air on the pattern and in the cured rubber. A mold release (petroleum jelly) may be applied on the pattern first to improve release.
7. Allow the rubber to cure for 16-24 hours at 75±5°F (24°C) before removing the cured rubber mold from the pattern. For best results, allow the mold to air cure an additional 24 hours before using it in production. Full cure is achieved in 3-7 days.

PROCESSING INFORMATION

CATALYZED PROCESSING PROPERTIES ARE AFFECTED BY TEMPERATURE AND HUMIDITY VARIATION

1. For best results, mix and cure the material at 75°F (24°C) and 50% relative humidity.
2. Higher temperature and humidity will decrease the work life and pot life of the material. The faster cure will also affect the flow properties. Refrigeration of the base prior to use in hot environments has shown to improve the handling properties of this material.
3. Lower temperatures and humidity will increase the work life and pot life of the material. The slower cure will increase the flow time. Cure temperatures below 68°F (20°C) are not recommended and have been found to cause a reduction in final cure hardness and properties.
4. It is important that the catalyst containers are tightly closed after use to prevent contamination.

Storage and shelf life

BLUESIL™ RTV 3044 when stored in its original unopened packaging, at a temperature of 24°C (75°F), may be stored for 18 months from the date of manufacture. Beyond this date, Bluestar Silicones no longer guarantees that the product meets the sales specifications

Safety

Please read the container labels for **BLUESIL™ RTV 3044** or consult the Material Safety Data Sheet (MSDS) before handling for safe use, physical and health hazard information. The MSDS is not included with the product packaging, but can be obtained by contacting Bluestar Silicones at 866-474-6342 or consult your Bluestar Silicones representative.

Packaging

BLUESIL™ RTV 3044 is available in 20 kg and 200 kg containers.

BLUESIL™ is a Trademark of **Bluestar Silicones**

 EUROPE	 NORTH AMERICA	 LATIN AMERICA	 ASIA PACIFIC
Bluestar Silicones France 21 Avenue Georges Pompidou F69486 Lyon Cedex 03 FRANCE Tel. (33) 4 72 13 19 00 Fax (33) 4 72 13 19 88	Bluestar Silicones USA Two Tower Center Boulevard Suite 1601 East Brunswick, NJ 08816-1100 United States Tel. (1) 732 227 2060 Fax (1) 732 249 7000	Bluestar Silicones Brazil Ltda. Av. Maria Coelho Aguiar, 215 Bloco G - 1º Andar 05804-902 - São Paulo - SP - Brazil Tel. (55) 11 3747 7887 Fax (55) 11 3741 7718	Bluestar Silicones Hong Kong Trading Co. Ltd. 29th Floor, 88 Hing Fat Street Causeway Bay Hong Kong Tel. (852) 3106 8200 Fax (852) 2979 0241

Warning to users

The information contained in this document is given in good faith based on our current knowledge. It is only an indication and is in no way binding, particularly as regards to infringement of or prejudice to third party rights through the use of our products. **BLUESTAR SILICONES** warrants that its products comply with its sales specifications. This information must not be used as a substitute for necessary prior tests, which ensure that a product is suitable for a given use. Determination of the suitability of product for the uses and applications contemplated by user and others shall be the sole responsibility of user. Users are responsible for ensuring compliance with local legislation and for obtaining necessary certifications and authorizations. Users are requested to ensure that they are in possession of the latest version of this document; please contact **BLUESTAR SILICONES** for the latest version and any additional information.